




This tutorial will explain how to link Cre8Play products using the snap point in component drawings. This applies to the products that are designed to link together.




Single Post Swing
Add-A-Bay



Strato Rock & Ledge Rock
w/ Rope Link




Ledge Rock w/ Rope Link




Strato Rock w/ Slide
Attachment and Rope Link

Example Components:


Strato Rock with Rope Link tabs and Slide Attachment (PN 1000012), Spider Web Rope Link (PN 8000001) & Straight Slide (PN 200057)




Step 1: Insert the file (PN 1000012) into your drawing. There will be two “X”, snap points in the drawing. One snap point is located on the ground for the Rope Link attachment and one snap point is located on top of the Strato Rock for the Slide Attachment.




Step 2: Insert the file (PN 8000001) into your drawing. From the Rope Link snap point, move the Rope Link to the Strato Rocks snap point.




Step 3: The Rope Link should now be in line with the Strato Rock. Check that both snap points overlap.




Step 4: Insert the file (PN 1000230) into your drawing. From the Themed Post snap point, move the Themed Post to the Rope Links snap point.




Step 5: The Themed Post should be in line with the Strato Rock and Rope Link. Check that both snap points overlap.




Note 1: The Slide attaches only to one side of the Strato Rock Climber. The snap point is found on the top of the Strato and on top of the sit down deck of the Slide.




Step 6: Insert the file (PN 200057) into your drawing. From the Slide snap point, move the Slide to the Strato Rock snap point.




Note 2: Check that both snap points overlap.




Step 7: The snap points and snap point text are located on the layer”_Snaps”. Once finished, turn off the layer to hide snap points and snap point text.



Note 3: The Single post swings can have additional bays that can be added to them. (The snap point can be found underneath the upright post)



Step 1: Insert the file (PN 1000126) into your drawing. Insert the file (PN 1000130) into your drawing. From the Single Post Add-a-Bay snap point, move the Swing Add-a-Bay to the Single Post Swing snap point. Check that both snap points overlap.



Step 2: The snap points and snap point text are located on the layer”_Snaps”. Once finished, turn off the layer to hide snap points and snap point text.