




The Leaf Bench is inspired by nature. Place them facing each other or spaced out to get different social interactions between users. This durable Glass Fiber Reinforced Concrete (GFRC) constructed bench impresses with its styling.







Leaf Bench  
5000003

L: 6'-2" x W: 2'-2" x H: 2'-9"  
800 LBS





Blends into natural environment

*Installation Instructions*



~ All dimensions are approximate ~

## Installation Instructions



### Included Items:

Item	Description	Quantity
Leaf Bench	Site Amenity	1
Anchor Bolt 1/2" x 3"	Mounting Hardware	4

~ All dimensions are approximate ~




## Installation Instructions

**NOTE:** Read installation instructions thoroughly before starting installation process.

**Step 1:** Lay out the area and prepare the site for install. Concrete must be installed over a solid, level base. Check local soil condition and codes.

**Step 2:** Pour a concrete slab for the Leaf Bench. Refer to the typical slab detail on this page. The concrete should be flush with the surface. Allow time for the concrete to completely cure before continuing.

**Step 3:** Place Leaf Bench into final installation location. To anchor your product down to the slab, use the included hardware.



### NOTES PRIOR TO CONSTRUCTION:

- Use appropriate equipment to lift and move the site amenity.
- Check local codes and requirements prior to digging or installing any equipment.

~ All dimensions are approximate ~

## Installation Instructions


**Step 4:** Locate your anchor bolts, supplied by Cre8Play. Using the proper standard drill bit size noted in the installation table, drill the concrete to the appropriate hole depth (C).

**Step 5:** Insert the anchor bolt into the hole and tighten until the bolt is fully seated. Do NOT over tighten the anchor bolts.


**Installation Table**

Anchor Bolt Size	ANSI Standard Drill Bit Diameter	Anchor Head (Socket Size) Diameter (A)	Minimum Embedment (B)	Hole Depth (C)
1/2" x 3"	7/16"	3/4"	2 1/2"	3 1/2"


**Anchor Bolt (Large Diameter Tapcon) Installation:**




**Mounting Detail**  
(Not to Scale)



**Step 1: Drill**



**Step 2: Anchor**



**NOTE: Always wear eye protection appropriate to the task at hand.**

~ All dimensions are approximate ~