




A fun sports themed balance and stepping feature. Constructed of durable Glass Fiber Reinforced Concrete (GFRC). This stepper will go well with Cre8Play's other sports themed play components.





L: 1' 6"
 W: 1' 6"
 H: 1' 4"
 200 LBS

Use Zone




Steppers shall be no greater than 12 in. (300mm) apart when intended for use by 2 through 5-year-olds and no greater than 18 in. (460 mm) apart when intended for use by 5 through 12-year-olds. This dimension shall be measured edge to edge between the adjacent stepping surfaces. (This measurement will be horizontal when adjacent steppers are at the same height and it will be diagonal when adjacent steppers are at different heights.)



Typical Component Footing Detail

Check local soil conditions.
(Not to Scale)



NOTE: Read installation instructions thoroughly before starting installation process.

Step 1: Lay out the area and prepare the site for install. Concrete must be installed over a solid, level base. Check local soil condition and codes. See product installation instructions for minimum use zone requirements to ensure proper spacing and adequate surfacing area.

Step 2: Refer to the typical in-ground footing detail on excavating a hole for the the component.

Step 3: Slide the 2 pieces of rebar into the holes on the base of the Baseball Stepper post. Place Baseball Stepper post onto the stone or porous block at the bottom of the excavated hole. Ensure any space between the bottom of the Baseball Stepper and top of grade will be completely covered by your particular type of surfacing. Temporarily brace the post.

Step 4: Pour a concrete footing for the Baseball Stepper. Refer to the typical footing section on the typical in-ground mounted footing page. This concrete should be flush with the ground level. Allow time for the concrete to completely cure before removing temporary bracing. Once the concrete is cured, fill the hole of the Baseball Stepper with Loctite PL 500 landscape block adhesive (or similar) adhesive. Slide the ball onto the post and allow the PLC adhesive to cure.

Step 5: Refer to the surfacing manufacturer for installation of an approved impact attenuating play surface around the Baseball Stepper a minimum of 6 feet in every direction.

Included Items:


Item	Description	Quantity
Baseball Stepper	Play Equipment	1
Baseball Stepper Post	Play Equipment	1
Rebar	Hardware	2

Items not provided:

Item	Description	Quantity
Loctite PL 500 landscape block adhesive (or similar)	Adhesive	1

NOTES PRIOR TO CONSTRUCTION:

- Use appropriate equipment to lift and move the play equipment.
- Check local codes and requirements prior to digging or installing any equipment.



NOTE: Always wear eye protection appropriate to the task at hand.